

SERVICE PARTS LIST

THE M.G. Series MGA TWIN CAM

Item No.	DESCRIPTION	Commencing (C) 501		Qty. per Vehicle		Unit of Issue	Type of Vehicle	MODIFICATIONS			REMARKS
		Part Number	Illus. No.	RHD	LHD			New Part Number	Change Point	Amdt. No.	
	SWITCHES										
1	Switch—panel light	47H5188	NB1	1	1						
2	Knob for switch	AHH5368	NB2	1	1						
3	Switch—ignition	AHH5369	NB3	1	1						
4	Lock and key—ignition switch	7H9830	NB4	1	1						
5	Key	ANK4646	NB5	2	2						
6	Switch—head and sidelamp	3H3098	NB6	1	1						
7	Knob for switch	AHH5360	NB7	1	1						
8	Switch—flasher	AMK5607	NB8	1	1						
9	Lever for switch	27H5511	NB9	1	1						
10	Nut fixing flasher switch (knurled)	17H5485	NB10	1	1						
11	Screw fixing lever	17H5483	NB11	1	1						
12	Washer for screw (spring)	17H5484	NB12	1	1						
13	Switch—map-reading lamp	27H5278	NB13	1	1						
14	Knob for switch	AHH5362	NB14	1	1						
15	Switch—starter	3H949	NB15	1	1						
16	Coupling—switch to control	3H950	NB16	1	1						
17	Bootee for terminal	8G548	NB17	2	2						
18	Switch—fog lamp	27H5278	NB18	1	1						
19	Knob for switch	AHH5366	NB19	1	1						
20	Switch—stop lamp	3H1894	NB20	1	1						
21	Switch—windscreen wiper	27H5278	NB21	1	1						
22	Knob for switch	AHH5364	NB22	1	1						
23	Switch—dipper	11G2007	NB23	1	1						
24	Screw—switch to bracket	AJD1243Z	NB24	2	2						
25	Washer for screw (spring)	LWZ203	NB25	2	2						
26	Bracket—dipper switch	AHH5780	NB26	1							
27	Screw—bracket to bulkhead	HZS0405	NB27	3							
28	Washer for screw (spring)	LWZ204	NB28	3							
29	Washer for screw (plain)	PWZ104	NB29	3							
30	Bracket—dipper switch	AHH5347			1			AHH5965	Com. (C) 2281		
31	Screw—bracket to bulkhead	PMZ0308			1						
32	Screw—bracket to bulkhead	CMZ0308			2				Fin. (C) 2280		
33	Washer for screw (cup)	7722			2						
34	Nut for screw	FNZ103			3						
35	Screw—bracket to goalpost				3			PFZ0810	Com. (C) 2281		
36	Washer for screw (spring)				3			LWZ203			

SERVICE PARTS LIST

THE M.G. Series MGA TWIN CAM

Item No.	DESCRIPTION	Commencing (C) 501		Qty. per Vehicle		Unit of Issue	Type of Vehicle	MODIFICATIONS			REMARKS
		Part Number	Illus. No.	RHD	LHD			New Part Number	Change Point	Amdt. No.	
	Switches—continued										
1	Box—control	3H1835	NB30	1	1						
2	Screw fixing control box	PMZ0320	NB31	2	2						
3	Washer for screw (spring)	LWZ203	NB32	2	2						
4	Nut for screw	FNZ103	NB33	2	2						
5	Washer (special)	AJD7212	NB34	2	2						
6	Box—fuse	1G2613	NB35	1	1						
7	Fuse (35-amp.)	7H5067	NB36	4	4						
8	Screw fixing fusebox	PMZ0310	NB37	2	2						
9	Washer for screw (spring)	LWZ203	NB38	2	2						
10	Nut for screw	FNZ103	NB39	2	2						
11	Switch—headlamp flasher (N. AMERICA)	BHA4116	NB40		1						} Optional extra
12	Relay—headlamp flasher (N. AMERICA)	3H1911	NB41		1						
13	Screw fixing relay	PMZ0308	NB42		2						
11	Nut for screw	FNZ103	NB43		2						
15	Washer for nut (spring)	LWZ203	NB44		2						