

SERVICE PARTS LIST

THE M.G. Series MGA TWIN CAM

Item No.	DESCRIPTION	Commencing (C) 501		Qty. per Vehicle		Unit of Issue	Type of Vehicle	MODIFICATIONS			REMARKS
		Part Number	Illus. No.	RHD	LHD			New Part Number	Change Point	Amdt. No.	
ELECTRICAL EQUIPMENT											
BATTERY											
1	Battery	N.S.P.	N1	2	2						
2	Screw—terminal	2K8645	N2	2	2						
3	Clamp—battery	AHH5166	N3	2	2						
4	Packing—battery clamp	AHH5169	N4	2	2						
5	Bolt—battery fixing (long)	AHH5167	N5	2	2						
6	Bolt—battery fixing (short)	AHH5168	N6	2	2						
7	Locknut for battery fixing bolt	FNZ204	N7	8	8						
8	Pad—battery (rubber)	AHH5170	N8	4	4						
9	Cover—battery	BHA4140	N9	2	2						
10	Cap nut—cover	BHA4147	N10	4	4						
11	Bolt—battery (long)	AHH5064	N11	2	2						Optional extra
12	Bolt—battery (short)	AHH5063	N12	2	2						
13	Nut for bolt	AJD8104Z	N13	4	4						
DYNAMO											
14	Dynamo	AEJ12		1	1						Correction. Was 11G220
15	Nut for shaft	47H5215	N14	1	1						
16	Washer for nut (spring)	LWZ207	N15	1	1						
17	Bearing—drive end	97H626	N16	1	1						
18	Bracket assembly—drive end	57H5083	N17	1	1						
19	Key for pulley	WKN404	N18	1	1						
20	Armature	7H5389	N19	1	1						
21	Coils—field	7H5071	N20	1 set	1 set	1					
22	Bracket assembly—commutator end	57H5082	N21	1	1						
23	Bush for bracket	7H5390	N22	1	1						
24	Oiler	17H5530	N23	1	1						
25	Spring—brush tension	7H5031	N24	1 set	1 set	1					
26	Brush	7H5028	N25	1 set	1 set	1					
27	Terminal	17H5433	N26	1	1						
28	Bolt—through-fixing	17H5217	N27	2	2						
29	Sundry parts	7H5376		1 set	1 set	1					