



SERVICE PARTS LIST

THE M.G. Series MGA TWIN CAM

Item No.	DESCRIPTION	Commencing (C) 501		Qty. per Vehicle		Unit of Issue	Type of Vehicle	MODIFICATIONS			REMARKS
		Part Number	Illus. No.	RHD	LHD			New Part Number	Change Point	Amdt. No.	
	<b>ENGINE MOUNTING</b>										
1	Bracket—front engine mounting—R.H.	AHH5065	AK1	1	1						
2	Bracket—front engine mounting—L.H.	AHH5703	AK2	1	1						
3	Screw—bracket to mounting plate—R.H.	HZS0508	AK3	2	2						
4	Nut for screw	LNZ105	AK4	2	2						
5	Screw—bracket to mounting plate—L.H.	CMZ0516	AK5	2	2						
6	Screw—bracket to mounting plate—L.H.	CMZ0520	AK6	1	1						
7	Nut for screw	LNZ105	AK7	3	3						
8	Washer for screw (spring)	LWZ205	AK8	4	4	24					
9	Washer for L.H. screw (plain)	PWZ105	AK9	1	1						
10	Screw—bracket to block	HZS0606	AK10	2	2						
11	Washer for screw (spring)	LWZ206	AK11	2	2						
12	Rubber—front engine mounting—R.H.	AHH5833	AK12	1	1						
13	Rubber—front engine mounting—L.H.	AHH5832	AK13	1	1						
14	Washer—engine mounting to bracket (spring)	LWZ205	AK14	4	4	24					
15	Nut—engine mounting to bracket	FNZ105	AK15	4	4						
16	Screw—mounting rubber to bracket—R.H.	HZS0505	AK16	4	4						
17	Screw—mounting rubber to bracket—L.H.	HZS0506	AK17	4	4						
18	Nut for screw	FNZ105	AK18	8	8						
19	Washer for screw (spring)	LWZ205	AK19	8	8	24					
20	Flexible bush—rear engine mounting	AHH5031	AK20	1	1						
21	Bolt for flexible bush	HBZ0826	AK21	1	1						
22	Washer for bolt	LWZ208	AK22	1	1						
23	Nut for bolt	LNZ108	AK23	1	1						
24	Plate—packing—L.H.	AHH5896	AK24	1	1						