



A2967

SERVICE PARTS LIST

THE M.G. Series MGA TWIN CAM

Item No.	DESCRIPTION	Commencing (C) 501		Qty. per Vehicle		Unit of Issue	Type of Vehicle	MODIFICATIONS			REMARKS
		Part Number	Illus. No.	RHD	LHD			New Part Number	Change Point	Amdt. No.	
	BUMPERS AND FITTINGS										
1	Bumper assembly (front)	N.S.P.		1	1						
2	Bar—centre	AHH5474	RK1	1	1						
3	Bar—corner—R.H.	AHH5486	RK2	1	1						
4	Bar—corner—L.H.	AHH5487	RK3	1	1						
5	Bolt—corner bar to centre bar	AHH5491	RK4	2	2						
6	Nut for bolt	FNZ105	RK5	2	2						
7	Washer for nut (spring)	LWZ205	RK6	2	2						
8	Washer for nut (special)	AHH5492	RK7	2	2						
9	Spring bar	AHH5476	RK8	2	2						
10	Bolt—spring bar to centre bar	AHH5479	RK9	1	1						
11	Nut for bolt	FNZ106	RK10	1	1						
12	Washer for nut (spring)	LWZ206	RK11	1	1						
13	Washer for nut (special)	AHH5494	RK12	1	1						
14	Bolt—spring bar to corner bar	AHH5480	RK13	2	2						
15	Nut for bolt	FNZ106	RK14	2	2						
16	Washer for nut (plain)	PWZ106	RK15	2	2						
17	Washer for nut (spring)	LWZ206	RK16	2	2						
18	Washer for nut (special)	AHH5494	RK17	2	2						
19	Over-rider assembly	AHH5478	RK18	2	2						
20	Moulding (P.V.C.)	AHH5488	RK19	4	4						
21	Bolt—over-rider to bumper bar	HBZ0620	RK20	2	2						
22	Washer for bolt (plain)	PWZ106	RK21	2	2						
23	Washer for bolt (spring)	LWZ206	RK22	2	2						
24	Washer for bolt (special)	AHH5494	RK23	2	2						
25	Bracket—starting-handle	AHH5477	RK24	1	1						
26	Grommet for outer stud	AHH5163	RK25	2	2						
27	Grommet for inner stud	AHH5164	RK26	2	2						
28	Nut—spring bar to stud	FNZ108	RK27	4	4						
29	Washer for nut (plain)	PWZ208	RK28	8	8						
30	Washer for nut (spring)	LWZ208	RK29	4	4						
31	Bumper assembly (rear)	N.S.P.		1	1						
32	Bar—bumper	AHH5481	RK30	1	1						
33	Spring bar	AHH5482	RK31	2	2						
34	Bolt—spring bar to bumper bar (outer)	AHH5480	RK32	2	2						
35	Nut for bolt	FNZ106	RK33	2	2						
36	Washer for nut (plain)	PWZ106	RK34	2	2						
37	Washer for nut (spring)	LWZ206	RK35	2	2						
38	Washer for nut (special)	AHH5494	RK36	2	2						
39	Bolt—spring bar to bumper bar (inner)	AHH5485	RK37	2	2						
40	Nut for bolt	FNZ106	RK38	2	2						
41	Washer for nut (plain)	PWZ206	RK39	4	4						
42	Washer for nut (spring)	LWZ206	RK40	2	2						
43	Washer for nut (special)	AHH5494	RK41	2	2						
44	Distance piece for bolt	AHH5483	RK42	2	2						
45	Distance tube for bolt	AHH5484	RK43	2	2						
46	Over-rider assembly	AHH5478	RK44	2	2						
47	Moulding (P.V.C.)	AHH5488	RK45	4	4						
48	Bolt—over-rider to bumper bar	HBZ0616	RK46	2	2						
49	Washer for bolt (spring)	LWZ206	RK47	2	2						
50	Washer for bolt (special)	AHH5494	RK48	2	2						

SERVICE PARTS LIST

THE M.G. Series MGA TWIN CAM

Item No.	DESCRIPTION	Commencing (C) 501		Qty. per Vehicle		Unit of Issue	Type of Vehicle	MODIFICATIONS			REMARKS
		Part Number	Illus. No.	RHD	LHD			New Part Number	Change Point	Amdt. No.	
	Bumpers and Fittings—continued										
1	Bracket—rear bumper mounting—R.H.	AHH5093	RK49	1	1						
2	Bracket—rear bumper mounting—L.H.	AHH5094	RK50	1	1						
3	Bolt—bracket to frame (3 3/4")	HBZ0730	RK51	2	2						
4	Nut for bolt	FNZ107	RK52	2	2						
5	Washer for nut (spring)	LWZ207	RK53	2	2						
6	Bolt—bracket to frame (4")	HBZ0732	RK54	2	2						
7	Nut for bolt	FNZ107	RK55	2	2						
8	Washer for nut (plain)	PWZ107	RK56	2	2						
9	Washer for nut (spring)	LWZ207	RK57	2	2						
10	Grommet for bracket	180383	RK58	2	2						
11	Nut—spring bar to bracket	FNZ108	RK59	2	2						
12	Washer for nut (plain)	PWZ208	RK60	4	1						
13	Washer for nut (spring)	LWZ208	RK61	2	2						