



A2690

SERVICE PARTS LIST

THE M.G. Series MGA TWIN CAM

| Item No. | DESCRIPTION                                  | Commencing (C) 501 |            | Qty. per Vehicle |     | Unit of Issue | Type of Vehicle | MODIFICATIONS   |              |                                     | REMARKS |
|----------|--|--------------------|------------|------------------|-----|---------------|-----------------|-----------------|--------------|-------------------------------------|---------|
|          |  | Part Number        | Illus. No. | RHD              | LHD |               |                 | New Part Number | Change Point | Amdt. No.                           |         |
|          | <b>INLET AND EXHAUST MANIFOLDS</b>           |                    |            |                  |     |               |                 |                 |              |                                     |         |
| 1        | Manifold—inlet                               | AEH21              | AJ1        | 1                | 1   |               |                 |                 |              |                                     |         |
| 2        | Plug for core hole                           | 2K8168             | AJ2        | 2                | 2   |               |                 |                 |              |                                     |         |
| 3        | Stud for carburetter                         | CLS2512            | AJ3        | 8                | 8   |               |                 |                 |              |                                     |         |
| 4        | Washer for stud (plain)                      | PWZ105             | AJ4        | 8                | 8   |               |                 |                 |              |                                     |         |
| 5        | Washer for stud (spring)                     | LWZ205             | AJ22       | 8                | 8   | 24            |                 |                 |              |                                     |         |
| 6        | Nut for stud                                 | FNZ105             | AJ5        | 8                | 8   |               |                 |                 |              |                                     |         |
| 7        | Joint for inlet manifold                     | AEH578             | AJ6        | 1                | 1   |               |                 |                 |              |                                     |         |
| 8        | Nut for manifold stud                        | FNZ106             | AJ7        | 5                | 5   |               |                 |                 |              |                                     |         |
| 9        | Washer for manifold stud (plain)             | PWZ106             | AJ8        | 5                | 5   |               |                 |                 |              |                                     |         |
| 10       | Washer for manifold stud (spring)            | LWZ206             | AJ9        | 5                | 5   |               |                 |                 |              |                                     |         |
| 11       | Nut for manifold stud (self-locking)         | LNZ206             | AJ10       | 2                | 2   |               |                 |                 |              |                                     |         |
| 12       | Washer for manifold stud (plain)             | PWZ106             | AJ11       | 2                | 2   |               |                 |                 |              |                                     |         |
| 13       | Manifold—exhaust (No. 1 and No. 4 cylinders) | AEH30              | AJ12       | 1                | 1   |               |                 |                 |              |                                     |         |
| 14       | Manifold—exhaust (No. 2 and No. 3 cylinders) | AEH31              | AJ13       | 1                | 1   |               |                 |                 |              |                                     |         |
| 15       | Stud for outlet flange                       | AEH194             | AJ14       | 6                | 6   |               |                 |                 |              |                                     |         |
| 16       | Washer for stud (spring)                     | LWZ206             | AJ15       | 6                | 6   |               |                 |                 |              |                                     |         |
| 17       | Nut for stud                                 | AEH195             | AJ16       | 6                | 6   |               |                 |                 |              |                                     |         |
| 18       | Joint for exhaust manifold                   | AEH574             | AJ17       | 1                | 1   |               |                 |                 |              |                                     |         |
| 19       | Nut for manifold stud                        | BNN105             | AJ18       | 6                | 6   |               | AHH5171         | Com. (E) 256    |              | Always use AHH5171 prior to (E) 256 |         |
| 20       | Washer for manifold stud (plain)             | PWN105             | AJ19       | 6/4              | 6/4 | 12            |                 |                 |              | Quantity reduced at (E) 113         |         |
| 21       | Washer for manifold stud (spring)            |                    | AJ20       | 6                | 6   | 24            | LWZ205          | Com. (E) 256    |              | ] Use from (E) 101                  |         |
| 22       | Washer for manifold stud (between manifolds) |                    | AJ21       | 2                | 2   |               | AEH603          | Com. (E) 113    |              |                                     |         |