



A2969

SERVICE PARTS LIST

THE M.G. Series MGA TWIN CAM

Item No.	DESCRIPTION	Commencing (C) 501		Qty. per Vehicle		Unit of Issue	Type of Vehicle	MODIFICATIONS			REMARKS
		Part Number	Illus. No.	RHD	LHD			New Part Number	Change Point	Amdt. No.	
	CLUTCH										
	CLUTCH PEDAL AND LINKAGE										
1	Pedal—clutch	AHH5694	E1	1							
2	Pedal—clutch	AHH5696			1						
3	Bush	185794	E2	1	1						
4	Pad for pedal (rubber)	AHH5100	E3	1	1						
5	Spring—pedal pull-off	180154	E4	1	1	6.					
6	Pin—clevis	CLZ0515	E5	1	1						
7	Washer for pin (plain)	PWZ105	E6	1	1						
	MASTER CYLINDER ASSEMBLY										
8	Master cylinder assembly	BHA4072		1	1						
9	Body	17H4476	E7	1	1						
10	Cap—filler	7H4379	E8	1	1						
11	Gasket	7H4720	E9	1	1						
12	Seal—valve	7H4750	E10	1	1						
13	Stem—valve	7H4751	E11	1	1						
14	Spacer—valve	17H4132	E12	1	1						
15	Plunger	17H4510	E13	1	1						
16	Seal—plunger	7H4976	E14	1	1						
17	Spring	7H4944	E15	1	1						
18	Push-rod	17H4544	E16	1	1						
19	Cover—dust	7H4757	E17	1	1						
20	Retainer—spring	7H4755	E18	1	1						
21	Washer—retaining	7H4756	E19	1	1						
22	Circlip	7H4451	E20	1	1						
23	Washer (spring)	7H4752	E21	1	1						
24	Seal—taper end	17H4500	F22	1	1						
25	Bolt fixing cylinder	HZS0510	E23	2	2						
26	Nut for bolt	LNZ205	F24	2	2						
27	Washer for nut (plain)	PWZ105	E25	2	2						
28	Locknut—master cylinder push rod	FNZ205	E42	1	1						
29	Fork end—master cylinder push rod	FEZ105	E43	1	1						
30	Pipe—master cylinder to hose	AHH5822	E26	1							
31	Pipe—master cylinder to hose	AHH5824			1						
32	Hose—clutch	11B5086	E27	1	1						
33	Locknut for hose	BCA4092	E28	1	1						
34	Washer (shakeproof)	2K7131	E29	1	1						
35	Gasket—hose to pipe	3H876	E30	1	1						
36	Clip—clutch pipe to master cylinder base plate	PCR0811	E31	1							
37	Clip—clutch pipe to bulkhead	PCR0811			2						

